

## iiyama Driver Instruction

Models concerned:

iiyama ProLite T2253MTS-B1 iiyama ProLite T2453MTS-B1

Touch controller: WiTouch Touch support (plug & play):

OS	Version	Kernel version	T2253_v.0035	T2453v.0035
Windows	XP	n/a	M	M
	Vista	n/a	M	M
	7	n/a	0	0
	8.1	n/a	0	0
	10	n/a	0	0
Ubuntu (Linux)	10.04.04LTS	2.6.32-38	0	0
	10.1	2.6.35	0	0
	11.04	2.6.38	0	0
	11.1	3.0.0.12	0	0
	12.04LTS	3.2.0.23	X	Х
	12.04.1LTS	3.2.0-29	X	Х
	12.04.2LTS	3.5.0-23	0	0
	12.04.3LTS	3.8.0-29	0	0
	12.04.4LTS	3.11.0-15	0	0
	12.04.5LTS	3.13.0-23	0	0
	12.1	3.5.0.17	0	0
	13.04	3.8.0.19	0	0
	13.1	3.11	0	0
	14.04LTS	3.13/3.16	0	0
	14.1	3.16	0	0
	15.04	3.19	0	0
Fedora (Linux)	15	2.6.38	0	0
	16	3.1.0.7	0	0
	17	3.3.4.5	X	Х
	18	3.6.10	0	0
	19	3.9.5.301	0	0
	20	3.11.10.301	0	0
	21	3.17.4.301	0	0
	22	4.0.4-301	0	0
	25	4.8	0	0
Raspberry pi (Linux)	jessie	05/07/2017	0	0
	Stretch	4.9.59-v7 #1047	0	0
	Stretch	4.14.34-v7 #1110	0	0

M: Mouse function onlyO: Touch function normal

X: Touch function abnormal

\*Note: iiyama does her utmost to provide accurate and complete information about the usage and availability of driver software as much as possible. However, we cannot guarantee all information is correct and will always work.